

Rocker Switch Cross Reference C&K to Electroswitch

STANDARD ROCKER AND PADDLE SWITCHES

BASIC SWITCH			OPTIONAL FEATURE CODES													
C&K		Electroswitch	Actuators		Terminations		Contact Materials		Sealing		Actuator Color		Frame or Bezels		Other	
Std.	U.L. ①		C&K	Electroswitch	C&K	Electroswitch	C&K	Electroswitch	C&K	Electroswitch	C&K	Electroswitch	C&K	Electroswitch	C&K	Electroswitch
7101	U11	B123														
7103	U13	B121												White ③	1P	
7105	U15	B127	J1 ②	J1										Black (Std.) ③	2P	
7107	U17	B131			A	A								Red ③	3P	
7108	U18	B126	J2 ②	J2	AV	AV1 ⑦					White	1				
7109	U19	B134	J3 ②	J3	AV2	AV2 ⑦	B	B								
7201	U21	B223	J5 ②	J5												
7203	U23	B221														
7205	U25	B227	J11 ③	J11	C	C					Black (Std.)	2		Black w/ L. E. D. Hole ③	4P	
7207	U27	B231														
7208	U28	B226	J21 ③	J21	V3	V3					Red	3		Green ③	5P	
7209	U29	B234			V4	V4										
7211	U211	B232	J37	J37												
7213	U213	B233			V5	V5					Green	5		Blue ③	6P	
7215	U215	B235	J47	J47										Bright Gray ③	8P	E ⑥
7301	U31	B323	J50 ②	J50	V6	V6					Blue	6				
7303	U33	B321														
7305	U35	B327	J51 ③	J50 ④	V7	V7								Yellow ③	9P	
7307	U37	B331														
7308	U38	N/A	J52 ③	J50 ⑤	W	W					Light Gray	8		Dark Gray ③	0P	
7309	U39	B334	J53 ②	J53	W1	W1										
7401	U41	B423	J60 ②	J60	W3	W3					Yellow	9		Bright Chrome ③	1M	
7403	U43	B421														
7405	U45	B427	J61 ③	J60 ④	W4	W4										
7407	N/A	B431														
7408	U48	N/A	J62 ③	J60 ⑤	Z	Z										
7409	U49	B434														
7411	U411	B432	J63 ②	J63	Z3	Z3					Dark Gray	0		Black (Std.) ③	2M	
7412	U413	B433														
7415	U415	B435												Satin Chrome ③	3M	

① Electroswitch part numbers are supplied U.L. Approved as standard on switches with Q and G options.

② A complete C&K part number includes in **Word Form** an actuator color at the end of the part number. If none is indicated a black actuator will be supplied as standard. Ex. 7101J2ZB with red actuator is Electroswitch part number B123J2ZB3.

③ A complete C&K part number includes in **Word Form** an actuator color and bezel color at the end of the part number. If none is indicated a black actuator and bezel will be supplied as standard. Ex. 7101J51CBE with white actuator and red frame is Electroswitch part number B123J50CB22P.

④ A complete Electroswitch part number must include one of the following bezel codes. 1P, 2P, 3P, 5P, 6P, 8P, 9P, 0P.

⑤ A complete Electroswitch part number must include bezel code 4P.

⑥ Epoxy is standard on all terminal options.

⑦ Verify momentary position on '26', '31', and '33' circuits. See pages 24 and 30 Pos. "C" or consult factory.

⑧ See page 24.

SELECTION GUIDE

