

Electroswitch Part List

PS Series

[Pages 4-13 in Miniature Switch Catalog](#)

PS1-100B
PS1-100G
PS1-100Q
PS1-112G
PS1-113G
PS1-121Q

PS1-123Q
PS1-200B
PS1-200Q
PS1-212B
PS1-212G
PS1-221B
PS1-221Q
PS1-223B
PS1-223G

PS11-100B
PS11-100G
PS11-200B
PS11-200G

PS14-1122B
PS14-1122Q
PS14-1124B
PS14-1124Q
PS14-112G
PS14-1132Q
PS14-200Q
PS14-2122B
PS14-2122Q
PS14-2124B
PS14-2124Q

PS15-100Q
PS15-1122B
PS15-1122Q
PS15-1124B
PS15-1124Q

Electroswitch Part List

PS Series

[Pages 4-13 in Miniature Switch Catalog](#)

PS15-2122B
PS15-2122G
PS15-2122Q
PS15-2124B
PS15-2124Q

PS16-1122B
PS16-1122Q
PS16-1124B
PS16-1124Q
PS16-2122B
PS16-2122Q
PS16-2124B
PS16-2124Q

PS17-1122B
PS17-1122Q
PS17-1124B
PS17-1124Q
PS17-2122B
PS17-2122Q
PS17-2124B
PS17-2124Q

PS2-100B
PS2-100Q
PS2-111Q
PS2-121B

PS2-200B
PS2-200Q
PS5-100Q
PS6-100Q
PS7-100B
PS7-200B

PS71-100B
PS71-100G
PS71-200B
PS71-200G

Electroswitch Part List

PS Series

[Pages 4-13 in Miniature Switch Catalog](#)

PS72-100B

PS72-100G

PS72-200B

PS72-200G

PS73-100B

PS73-100G

PS73-200B

PS73-200G

PS8-100B

PS8-131B

PS8-200B

PS81-100B

PS81-100G

PS81-200B

PS81-200G

PS82-100B

PS82-100G

PS82-200B

PS82-200G

PS83-100B

PS83-100G

PS83-121G

PS83-200B

PS83-200G

PS9-100B

PS9-100G

PS9-123G

PS9-200G

PS9-211B

Electroswitch Part List

PS Series

[Pages 4-13 in Miniature Switch Catalog](#)

CAPS AND BEZELS

W-KN-16 (BLACK)
W-KN-16A (WHITE)
W-KN-16B (RED)
W-KN-17 (BLACK)
W-KN-17A (WHITE)
W-KN-17B (RED)
W-KN-18 (BLACK)
W-KN-18A (WHITE)
W-KN-18B (RED)
W-KN-32 (BLACK)
W-KN-32A (WHITE)
W-KN-32B (RED)
W-KN-52 (BLACK)
W-KN-52A (WHITE)
W-KN-52B (RED)
W-BZ-12 (BLACK)
W-BZ-12A (WHITE)
W-BZ12B (RED)