

Electroswitch Part List

WR&WP Series

[Pages 32-35 in Miniature Switch Catalog](#)

WP121J2ZB2
WP121J2ZQ
WP121J72AB2
WP121J72V3B2
WP123J2ZQ2

WP123J72AB2
WP123J72V3B2
WP126J2ZQ2
WP126J72AB2
WP126J72AV2B2

WP126J72V3B2
WP127J2ZQ2
WP127J72AB2
WP127J72AV2B2
WP127J72V3B2

WP131J2ZQ2
WP131J72AB2
WP131J72AV2B2
WP131J72V3B2
WP221J2ZQ

WP221J72AB2
WP221J72AV2B2
WP221J72V3B2
WP223J2ZQ2
WP223J72AB2

WP223J72AV2B2
WP223J72V3B2
WP226J2ZQ2
WP226J72AB2
WP227J2ZQ2

WP227J72AB2
WP227J72AV2B2
WP227J72V3B2
WP231J2ZQ2
WP231J72AB2

Electroswitch Part List

WR&WP Series

[Pages 32-35 in Miniature Switch Catalog](#)

WP231J72V2B2
WP231J72V3B2
WP232J2ZQ2
WP232J72AB2
WP232J72AVAB2

WP232J72V3B2
WP235J2ZQ2
WP235J72AB2
WP235J72AV2B2
WP235J72V3B2

WR121J1ZQ2
WR121J71AB2
WR121J71AV2B2
WR121J71V3B2
WR121J71V3Q2

WR123J1ZQ2
WR123J71AB2
WR123J71AV2B2
WR123J71V3B2
WR123J71V3Q2

WR126J71AB2
WR126J71AV2B2
WR126J71V3B2
WR126J71ZQ2
WR127J1ZQ2

WR127J71AB2
WR127J71AV2B2
WR127J71V3B2
WR127J71V3Q2
WR131J1ZQ2

WR131J71AB2
WR131J71AV2B2
WR131J71V3B2
WR221J1ZQ2
WR221J71AB2

Electroswitch Part List

WR&WP Series

[Pages 32-35 in Miniature Switch Catalog](#)

WR221J71AV2B2

WR221J71V3B2

WR223J71AB2

WR223J71AV2B2

WR223J71V3B2

WR226J71AB2

WR226J71AV2B2

WR226J71V3B2

WR226J71ZQ2

WR226J72AV2B2

WR226J72V3B2

WR227J1ZQ2

WR227J71AB2

WR227J71AV2B2

WR227J71V3B2

WR231J71AB2

WR231J71AV2B2

WR231J71V3B3

WR231JZQ2

WR232J1ZQ2

WR232J71AB2

WR232J71AV2B2

WR232J71V3B2

WR233J1ZQ

WR235J1ZQ2

WR235J71AB2

WR235J71AV2B2

WR235J71V3B2